



BEAMZ
MADE
EAZY

150.460 V2

PANTHER 25

QUICK START GUIDE

DMX CHANNELS

16 BIT	8 BIT	FUNCTION	VALUE	DESCRIPTION
1	1	Pan	000-255	Movement 0°-540°
2		Pan fine	000-255	
3	2	Tilt	000-255	Movement 0°-270°
4		Tilt fine	000-255	
5	3	Colour	000-007	White
			008-014	Red
			015-021	Yellow
			022-028	Cyan
			029-035	Green
			036-042	Pink
			043-049	Orange
			050-056	Blue
			057-066	White + Red
			067-076	Red + Yellow
			077-086	Yellow + Cyan
			087-096	Cyan + Green
			097-106	Green + Pink
			107-116	Pink + Orange
			117-127	Orange + Blue
			128-189	Colour wheel rotation, slow to fast CW
			190-193	Colour wheel rotation, stop
			194-255	Colour wheel rotation, slow to fast CCW
			6	4
008-015	Gobo 1			
016-023	Gobo 2			
024-031	Gobo 3			
032-039	Gobo 4			
040-047	Gobo 5			
048-055	Gobo 6			
056-063	Gobo 7			
064-071	Open			
072-079	Gobo 1 shake			
080-087	Gobo 2 shake			
088-095	Gobo 3 shake			
096-103	Gobo 4 shake			
104-111	Gobo 5 shake			
112-119	Gobo 6 shake			
120-127	Gobo 7 shake			
128-189	Gobo wheel rotation, slow to fast CW			
190-193	Gobo wheel rotation, stop			
194-255	Gobo wheel rotation, slow to fast CCW			

16 BIT	8 BIT	FUNCTION	VALUE	DESCRIPTION
7	5	Shutter	000-007	Shutter closed
			008-015	Shutter open
			016-131	Strobe effect, slow to fast
			132-139	Shutter open
			140-181	Fast close, slow open
			182-189	Shutter open
			190-231	Fast open, slow close
			232-239	Shutter open
			240-247	Random strobe
			248-255	Shutter open
8	6	Master dimmer	000-255	Dimmer 0-100%
9	7	Pan /Tilt speed	000-255	Speed 0-100%
10	8	Function	000-069	No function
			070-079	Black out by Pan/Tilt moves
			080-089	No function
			090-099	Black out by colour changes
			100-109	No function
			110-119	Black out by gobo changes
			120-199	No function
			200-209	Reset all
			210-249	No function
			250-255	Sound active mode
11	9	Dim mode	000-020	Standard
			021-040	Stage
			041-060	TV
			061-080	Architectural
			081-100	Theatre
			101-255	Standard

REMOTE CONTROL

STAND BY - Press this button to activate the Moving head.

FULL ON - Press this button to switch on the LED illumination. You must hold the button, then all LEDs will go on.

GOBO - Press this button to select the individual gobo via 1-9 buttons.

SOU/TILT - By means this button allows you to switch between fast and slow pan / tilt movements.

'DIMMER +' AND 'DIMMER -' - Press this button to adjust the brightness level.

STROBE - Press this button to activate the strobe function. You have 2 strobe effects. Short press functions as a flash function. If you want a strobe, you'll need to hold the button.

COLOR - Press this button to select the individual colour via 1-9 buttons. (1 Red; 2 Green; 3 Blue; 4 White, 5 Yellow, 6 Magenta, 7 Cyan, 8 Pink, 9 White all colours on). Adjust the brightness level via "DIMMER +" and "DIMMER -".

SOUND ON & OFF - These buttons activate and deactivate the sound active mode.

SHOW - Press this button to active the show mode. Use the 1-4 buttons to select your desired built-in programs.





BEAMZ

YOUR FUTURE
YOUR SKILLS
YOUR PLATFORM
YOUR PARTY
YOUR EVENT



is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.





150.016 **beamZ**

AC-120 Soft case

The **AC-120 Soft Case** is primarily designed to protect and extend the life of mobile lighting fixtures. Its wide opening allows for a variety of fixtures to fit inside and gear to be removed quickly and easily. It fits other products and accessories as well. Suitable for mobile DJs, Karaoke rigs and working bands.

Product colour : Black

Dimensions: Internal : 19 x 10.5 x 10 inch // 482 x 266 x 254mm

Weight (kg) : 0,75

- Quality protection for mobile lighting fixtures
- Secured zipped pocket for storing extra Lamps, Clamps, Cables and other Accessories
- Saves valuable transport space by allowing fixtures to be stacked without having to be boxed
- Secure view windows make it easy to identify specific fixtures even after they have been packed
- Affordable padded soft case



177.906 **RL CONNEX**

CX100-6 DMX Cable XLR Male - XLR Female 6m

PD Connex professional HQ 6 meter DMX signal cable. This flexible signal cable is fitted with high quality XLR connectors and guarantees a trouble-free and reliable DMX signal transmission. Supplied including cable tie.

IP rating : N/A
Select both plugs : 3-pin XLR (M), 3-pin XLR (F)
Lead length : 6m
Conductor : 28x0.1mm
Outer diameter : 6mm
Shielding : 60x0.1mm
Impedance : 120 Ohm
Weight (kg) : 0,30

- Professional flexible cable
- High quality metal connectors
- Cable tie included
- Various lengths available