



**G002GKA**  
**Bubble Machine**  
**With Remote Control (MkII)**



**Instruction Manual**

## **IMPORTANT**

### **Installer and Users please note:**

These instructions should be read carefully and left with the user of the product for future reference.

### **BEFORE USE**

You must inspect the product including its power supply for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

### **PRODUCT SAFETY**

This machine uses a wheel on a motorised axis. The wheel rotates through the liquid reservoir to create bubbles.

### **WARNINGS**

- This item can be used by children aged 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision and instruction concerning the use of the item in a safe way and understand the hazards involved.
- Children should be supervised to ensure that they do not play with the item.
- Do not place on carpet or other soft surfaces.
- Do not point the bubble output towards sensitive electronic equipment.
- Do not put anything apart from bubble fluid in the tank (except when cleaning as described in MAINTENANCE section).
- Do not move the unit whilst it is operating. Disconnect from the power supply and empty the tank before moving.
- For indoor use only.
- Do not use in bathrooms, or in wet or damp locations.
- Arrange the cable so that it cannot cause a trip hazard.
- The unit must be disconnected from the power supply before filling or emptying the tank.
- Do not allow fluid to enter the rear of the unit. If fluid does accidentally enter the rear of the unit disconnect it from the power supply & clean thoroughly before use.
- Do not overfill the tank.
- Clean any overflow/spillages immediately with a damp cloth.
- Fluid may cause spots/bleaching on cloth/upholstery etc.
- Warn other users & room occupants floors and hard surfaces may become slippery when in use.
- Do not drink the bubble fluid.
- Disconnect the power supply from the mains when not in use.
- Do not leave this item unattended when switched on.
- Do not leave fluid in the tank when not in use.

#### **Note:**

After prolonged use, the floor immediately in front of the unit may become slippery.

### **GENERAL SAFETY REQUIREMENTS**

Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy.

For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years.

It is recommended that all building be fitted with smoke alarms (it is mandatory for new buildings).

## **OPERATION**

### **To operate:**

Place the G002GKA on a firm flat surface. Ensure that the bubble outlet (at the front) is not obstructed. Alternatively, the appliance may be suspended from the attached hanging bracket. The unit must be suspended in a horizontal position and not tilted. Plug the power supply into a 13 Amp mains socket and attached to lead to the unit via the 12V socket on the rear of the unit.

### **Mode: Always on**

Move the switch on the rear panel to position I. The unit should now continually function until switched off

### **Remote Control Function:**

Move the switch on the rear panel to position II

Using the remote control use the on/off buttons to switch the unit on or off.

### **To Switch Off:**

Move the switch to (0) Position

### **To fill the tank:**

Disconnect from its power supply.

Fill the tank (at the front) with Venü Benchmark Bubble Fluid (catalogue numbers: FL801 for a 1 litre bottle or FL805 for a 5 litre bottle) taking care not to allow any fluid into the rear of the unit.

### **To empty the tank:**

Disconnect from the power supply

Use a funnel (not provided) and tip the bubble machine forwards and sideways so that the unused bubble fluid flows out of the front corner of the tank taking care not to allow any fluid to run into the back of the unit. Return the unused fluid to the bottle. Dry the tank with a cloth or paper towel before moving or storing away.

## **MAINTENANCE**

### **Cleaning:**

Clean the outside of the unit with a soft damp cloth, with a drop of washing-up liquid.

### **To clean the appliance:**

Empty out any residual bubble fluid.

Rinse the tank with water.

If the power supply is damaged, it must be replaced by a like for like product authorised by the manufacturer.

## **FAULT-FINDING**

### **Unit Does Not Function:**

- 1) Check the power supply is plugged into a wall socket and the socket is switched on.
- 2) Make sure the lead is plugged into the socket in the back of the unit and the switch is in the correct setting.
- 3) If using the remote control follow the above advice but also check that there is a battery in the remote control.

## **PAT TESTING**

When used in a workplace, this product must be safety-tested yearly by a qualified electrician (PAT Tested) in order to comply with the Electricity at Work Regulations.

If hired out, it must be PAT tested prior to each hire.

We recommend that it is PAT tested regularly when used in a domestic environment.

## **DISPOSAL AND RECYCLING**

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

## **TECHNICAL SPECIFICATION**

Dimensions:.....	230×215×190 mm
Weight: .....	1.7 kg (Net)
Plug in Mains Power Supply: .....	230V in 12V out 6W
Bubble Projection Distance:.....	Up to 3m
Tank Capacity:.....	0.6 litres
Remote Control Battery.....	1 x CR2025 (not supplied)
Effective Working Distance.....	Up to 3m

## **SERVICE WARRANTY**

Electrovision guarantees the product free from defects in materials and workmanship for a period of one year.

Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit , then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on (0845) 459 4816. The help desk is open from 8 am until 1 pm.

Electrovision Ltd.,  
Lancots Lane, Sutton,  
St. Helens, Merseyside.  
WA9 3EX

website: [www.electrovision.co.uk](http://www.electrovision.co.uk)